





SOFT, DRY CLOTH



CHEMICAL




HEAT



KEEP DRY



HANDLE WITH CARE




DO NOT USE KNIFE

ASSEMBLY INSTRUCTION


MODEL : EC 60122-S5V - EMMA MEUBLE TV / TV KAST / TV CABINET

HARDWARE	A	B	C	D	E	F1	F2	G	H	I	J	K	L	M	N
	PLASTIC DOWEL M8X25 1X46	CB SCREW M3.5X16 1X16	CB SCREW M4X30 1X4	CSK CAP M6X40 1X8	CSK CAP M6X50 1X4	MINIFIX 5654 22 SETS	METAL SHELF SUPPORT 1X12	CAP 1X12	PLASTIC PIN 1X6	POWER NAIL 6/8 1X38	RA01835 ROUND HANDLE - METAL 1X2	HANDLE SCREW M4X22 1X2	ALUMINIUM HINGES 7/8" 4 SETS	ALLEN KEY 1X1	


Part List




Step 1




Step 2




Step 3



Step 4




Step 5






SOFT, DRY CLOTH



CHEMICAL



HEAT



KEEP DRY



HANDLE WITH CARE




DO NOT USE KNIFE


ASSEMBLY INSTRUCTION

MODEL : EC 60122-S5V - EMMA MEUBLE TV / TV KAST / TV CABINET


Step 6




Step 7




Step 8




Step 9




Step 10




Step 11



Step 12




Step 13






SOFT, DRY CLOTH




CHEMICAL



HEAT



KEEP DRY



HANDLE WITH CARE




DO NOT USE KNIFE


ASSEMBLY INSTRUCTION

MODEL : EC 60122-S5V - EMMA MEUBLE TV / TV KAST / TV CABINET


Step 14




Step 15




Step 16



Step 17



Step 18



Completed

