





SOFT, DRY CLOTH



CHEMICAL



HEAT



KEEP DRY



HANDLE WITH CARE




DO NOT USE KNIFE

ASSEMBLY INSTRUCTION


MODEL : EC 60115-S5V - ELITE TV KAST / MEUBLE TV / TV CABINET

HARDWARE	A	B	C	D	E	F	G	H	I	J	J1	J2	K	L	M
	PLASTIC DOWEL M8X25 1X40	CB SCREW M3.5X16 1X8	CB SCREW M4X30 1X2	CSK CAP M6X40 1X6	MINIFIX 5654 18 SETS	METAL SHELF SUPPORT 1X8	CAP 1X14	HINGES (OUTSIDE) 5/8 2 SETS	POWER NAIL 6/8 1X35	HANDLE VSC 16 (SILVER) 1X1		P/H SCREW M4X24 1X2	PLASTIC PIN 1X6	ALLEN KEY 1X1	CSK CAP M6X50 1X4


PART LIST




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7



STEP 8




STEP 9






SOFT, DRY CLOTH



CHEMICAL



HEAT



KEEP DRY



HANDLE WITH CARE




DO NOT USE KNIFE



ASSEMBLY INSTRUCTION

MODEL : EC 60115-S5V - ELITE TV KAST / MEUBLE TV / TV CABINET

STEP 10





STEP 11





BACK VIEW

STEP 12





BACK VIEW



STEP 13




STEP 14







STEP 15



STEP 16



STEP 17



COMPLETED

